



*Scan Sport, Inc.*

May Street • P.O. Box 700 • Enfield, New Hampshire 03748-0700 USA

Tel: (603) 632-9500

Fax: (603) 632-5611

web: [www.pakboats.com](http://www.pakboats.com)

e-mail: [info@pakboats.com](mailto:info@pakboats.com)

## **PAKBOATS FOLDING CANOES SPRAY COVER INSTALLATION**

(COVER STYLE THRU 2004)

### Your Spray Cover should include:

- 1 Spray cover
- 1 Bag of snaps
- 1 Snap installation kit

### Installation Procedure:

1. Assemble the canoe you want to install the cover on.  
(Leave out the black end caps).
2. Place the ends of the spray cover over the ends of the canoe and set the snaps.  
(The snaps for the end caps have matching snaps on the spray cover).  
Please note that the openings on the cockpit skirts should face the bow.
3. Mark the positions on the canoe that correspond to snaps on the spray cover.
4. Disassemble the canoe.
5. Install snaps using the procedure described on the snap installation kit.
6. Glue D-rings on the side of the boat to hold the straps at the sides of the cover.  
(To position the D-rings you need to reassemble the canoe or wait until the next time the canoe is assembled)



QUALITY FOLDING BOATS